

VICTORY CITY

Feb. 16, 1988

CODES

SEB - SPLINTER ELEVATOR BUILDING, FRONT & REAR

- X - Elevator Overhead
- P - Elevator Pit
- R - Random Elevator, stops at all Sky Lobbies, floors: 13, 25, 37, 48, 59, 70, 81, 92 & Main Lobbies, floors: 1, 5, 9. Stops only when button is pressed for one of above floors.
- AF - All Floors, includes all floors between nearest Sky Lobby above and below, and the Sky Lobbies themselves. Elevator stops at all floors for which a button is pressed.
- SE - Service Elevator for Elev. Overhead & Roof Maintenance.

Orville Simpson II
3417 Erie Ave., Apt. 406
Cincinnati, Ohio 45208

Phone: 513-871-9571